



# Towel Rail

## User Friendly Guide



# Things to note.

You can use your towel rail in manual mode and simply turn the temperature up and down using the - or + keys.

## Alternatively....

You can use the timer mode to set timings so the radiator comes on and off as you wish routinely.

If you turn the radiator off at the wall, it will remember the settings but not the time. You will have to re-set the time every time you turn it back on if you are using it in a timed mode.

# Understanding the buttons.

Standby Screen

Button 1 - Increase temperature / time / comfort selection

Button 2 - Program button

Button 3 - Standby button

Button 4 - Decrease temperature / time / comfort selection



# To set the date & time

1. From Standby mode (Press button 3 if you need to enter this mode.)
2. Press and hold button 4 (-) for 3 seconds. You should now see 'Set' displayed.
3. Now press button 1 (+) until you see 'tEd' at the bottom of the screen, if you already see this, move to step 3
4. Now press button 2 (prog)
5. You should now see numbers 1 – 7 flashing on the screen. These represent the days of the week, day 1 is Monday, day 2 is Tuesday and so on, with Saturday and Sunday being day 6 and 7. Use the (+) and (-) buttons to select the current day.
6. Now press (prog) to take you to the clock, the hours will flash, use the (+) and (-) buttons to select the current hour
7. Now press button 2 again to take you to the minutes and use the (+) and (-) buttons to select the current minute.
8. Now press button 2 again and you will be taken back to the standby screen.

# To program the towel rail

- From standby mode,
- press button 4 (-) for 3 seconds, you will see 'Set' at the top of the screen as you did when you set the time.
- Press button 1 (+) button until you see 'prog' at the bottom of the screen, you may see this already so you can move to step 4.
- Now press button 2 'prog' button to enter edit mode, you will
- now be presented with a big clock which looks a bit like an old fashioned timer on a gas boiler.
- You will automatically be at the very start of the week, so you will be at 00:00 on day 1 – midnight on a Sunday night / Monday morning. You can now set the towel rail to be in either comfort or your set back temperature in hourly intervals over 24 hours, for 7 days.
- For every hour that you want to be in your set back temperature, you press button 4 (-) and for every hour you want the radiator to be in comfort mode, you press button 1 (+). You should notice that when you have selected your comfort temperature, a block will appear in the relevant time zone and when you select your setback temperature, there is no block.
- Once you have completed the full 24 hours of the day, you can press button 2 'prog' to move on to day 2. If you want to repeat the same times as day 1, just press button 2 'prog' again to move on to day 3.
- If you want to change the timings, for example on days 6 and 7 for the weekend, you simply press the (+) and (-) buttons again to select your comfort or set back temperatures for your hourly intervals.



# To set your temperatures

1. From Standby,
2. Press the 'On' button
3. Press the 'Prog' button twice, then you should see a sunshine on the screen.
4. Use the (+) and (-) buttons to select your desired comfort temperature shown at the top of the screen.
5. Once you have selected your desired set point for your comfort temperature, press 'prog' again and you will see the sunshine has disappeared and a moon has appeared.
6. Use (+) and (-) buttons to select your desired set back temperature.
7. Press 'prog' again, and you will now see this screen, leave it here now and you shouldn't need to press anything else.

# To use in manual mode.

To use the towel rail in manual mode, simply set the timings on the radiator following the process on the 'set your timings' page, selecting the 'comfort' setting, so press button 1, for every hour of every day. You should then have full blocks all the way around the circular clock.

Now all you need to do is to remember to use button to increase the temperature set point and button 4 to decrease the temperature set point

# Screen Lock & Open window feature

**To lock the screen**, press and hold button 2 for 3 seconds. To unlock the screen, repeat this process.

**To activate or de-activate the open window feature**, from the standby screen, press button 4 for 3 seconds. Now use button 1 to scroll between 'yes' and 'no' on the screen. Press button 2 when you have selected no to deactivate or yes to have the feature enabled.





# Infa-red Remote Control

The buttons on the towel rail remote control work exactly the same as they do on the towel rail. You can follow the same instructions, the only real difference is the timeline is a long line along the bottom of the screen, rather than a round 24 hour clock.

The remote comes with a wall mounting bracket for storage, but please note you have to point the remote control towards the control panel on the radiator.

There is no backlight on this remote.