


# Smartpanel Easy use guide



Button A is the Power button and will switch the unit between Standby and Heating from any mode

Button B will reduce temperature or change the settings down

Button C will Increase the temperature or move the settings up

Button D will switch between Programs P1-P2-P3 when the Clock is in the top right

Button E will change between the 7 modes:

1. Sunshine symbol/ Manual Control
2. Moon Symbol/ Economy Temp

Set these two temps before continuing to programming, as they are used in this mode.

- Frost Symbol/Frost protection
- Parasol Symbol/Holiday Mode
- Clock Symbol/program selection
- Countdown timer 1-9 hours
- Boost/between 5 – 120 Minutes of full power


Manual Mode:

Turn the unit on with Standby button A, then use mode button E to select the sunshine symbol if not already selected.

Use button B & C to increase or decrease the temperature on the heater, and then it will apply that temperature ongoing until you change mode or turn it off.

### Setting a program

There are two programs below – P1 & P2



And one you can program yourself – P3


You can make your own program (P3) for each day of the week by following these steps:

Turn the radiator to off/stand-by mode using button A

The standby symbol will be showing at the top of the screen

Press button D for 3 seconds this opens the menu, showing tEd, and then using the plus+ (button C)

Press once so that “Prog” appears and press button D to select.



The programme will start on the first day of the week Monday/1 and at 0:00 using the 24 hour clock

The day is programmed in one hour slots at either sunshine temp or moon temp


Pressing the plus+ (button C) will give you an hour of the comfort / sun temp for every press

Pressing the minus - (button D) will give you an hour of the economy /moon temp

When you are finished with day one, press button D and it will copy that program to the following day 2, which can then be programmed differently if required.

If not, press button D again to copy the program to day 3,4,5 etc.

Once you are happy with your programs, press button D on day 7 and the heater will revert to standby position.

To get to your programming and start it, press the standby button A, followed by button E until the timer symbol is showing in the top corner 

And then button D to cycle through the two preset programs P1 and P2 above or to your newly created program P3.

Once P3 is selected, you can leave the heater in this mode and it will continue to follow your set weekly instructions.